



Programming procedure for Beninca Almosfera T2WK & T4WK

Take a working remote and your new remote then:

1. Press and hold the 1st button on the new remote (the light will begin to flash after 5 seconds) keep this button held in until programming is complete.
2. Place the working remote nose to nose with the new remote then press and hold in the button which you would like to copy (the one that works your gates or door)
3. The light on the new remote will go off when programming is complete.



“If you need help give us a call on 01302 700650”