



Programming procedure for Cardale E-King remote

1. Take an existing working remote and your new remote and plug them in to each other using the 3 pin plug provided with your new remote.
2. Press and hold in the button on your existing working remote that you normally use to open your door or gate. Keep this button held in until programming is complete.
3. Press and hold the same button on the new remote. The LED on the new remote will flash fast for a few seconds then stay on steady. Now release both buttons at the same time. Unplug the remotes. Programming is now complete.



“If you need help give us a call on 01302 700650”