



Programming your new Aprimatic TR2 or TR4 remote, Stand as close to the gate or door receiver, take an existing working remote and your new remote then:

1. Press ALL of the buttons at the same time (2 buttons on 2 channel remotes and 4 buttons on 4 channel remotes) of a remote which is already in use until you hear the receiver make a continuous beeping noise (the beep continues for a maximum of 30 seconds, within which the new remote must be saved). then release.
2. Press All of the buttons on the new remote at the same time. The sound will stop for a moment (approximately 1.5 seconds) and then start again.
3. Press a button on the new remote which you would like to use to operate your system. The sound will stop for a moment (approximately 1.5 seconds) and then start again.
4. Wait for the beeping to stop then try your new remote.

Note: if all the buttons are not pressed down at the same time, the receiver does not recognize the new remote control.



"If you need help give us a call on 01302 700650"



Programming your new Aprimatic TR2 or TR4 remote, Stand as close to the gate or door receiver, take an existing working remote and your new remote then:

1. Press ALL of the buttons at the same time (2 buttons on 2 channel remotes and 4 buttons on 4 channel remotes) of a remote which is already in use until you hear the receiver make a continuous beeping noise (the beep continues for a maximum of 30 seconds, within which the new remote must be saved). then release.
2. Press All of the buttons on the new remote at the same time. The sound will stop for a moment (approximately 1.5 seconds) and then start again.
3. Press a button on the new remote which you would like to use to operate your system. The sound will stop for a moment (approximately 1.5 seconds) and then start again.
4. Wait for the beeping to stop then try your new remote.

Note: if all the buttons are not pressed down at the same time, the receiver does not recognize the new remote control.



"If you need help give us a call on 01302 700650"